Maxum Air

Battery Backup Air Pump

Parts Diagram & Identification



▲ S-1801

Features

- 1. Ideal for desktop use and operates quietly while providing air for your fish. The low maintenance design makes it great for transporting fish.
- 2. Equipped with a Lithium-ion battery that provides up to 24 hours of operation during power outages or while transporting fish.
- 3. Choose between continuous or interval air supply modes and dual airline outputs for customizable aeration.

Quick Installation

Unpack your new Maxum Air Battery Backup Air Pump. Inspect all its components and confirm all parts are included before using.

Report any damages or missing components to:

Toll Free: (877) 374 9981

Email: warranty@jbjaquarium.com

- 1. Battery must be installed before operating air pump.
- 2. Charge Maxum Air to full capacity before operating on battery power. Battery level is indicated by the number of LEDs lit (1 = 25%, 2 = 50%, 3 = 75%, 4 = 100%).
- 3. Attach airline tubing to dual outputs and install ends in aquarium.
- 4. Power on Maxum Air. Adjust the level of airflow strength from 1-4 (indicated by LEDs) using the +/- buttons.
- 5. Interval Mode will supply airflow for 7 seconds on and 7 seconds off at the set airflow strength.

Notice

1. Always unplug and power off Maxum Air air pump before inspecting or disassembling for any reason.

Safety Instructions

DANGER - TO AVOID POSSIBLE ELECTRICAL SHOCK.

Special care should be taken to avoid possible electric shock, since water is employed in the use of aquarium equipment. Do not attempt any repairs by yourself; return the appliance to an authorized service facility for service, or discard the appliance.

- 1. If the appliance falls into water, DON'T reach for it! First, unplug it and then retrieve it. If electrical components of the appliance get wet, unplug the appliance immediately.
- 2. Carefully examine the appliance after installation. Unplug the appliance if there is water on parts not intended to get wet.
- 3. Do not operate any appliance if it has a damaged cord or plug, or if it is malfunctioning, or if it has been dropped or damaged in any manner.
- 4. Arrange a "drip loop" for each cord connecting an aquarium appliance to an outlet. The "drip loop" is the part of the cord below the level of the outlet that prevents water from traveling along the cord and coming in contact with the outlet.
- If the plug or outlet should get wet, do not unplug the cord. Disconnect the fuse or circuit breaker that supplies power to the appliance. Once the power has been disconnected, unplug the cord and examine it for the presence of water in the outlet.
- 6. Always unplug the appliance from an outlet when it is not in use. Also unplug it before cleaning, and prior to disconnecting or attaching parts. Never yank the cord to pull the plug from the outlet. Grasp the plug and pull to disconnect.
- 7. The filter is designed to operate while filled with water. If the filter runs "dry" over an extended period of time, the motor should be examined to determine if its plastic surfaces have warped or melted. If so, replace the motor.
- Do not use an appliance for anything other than its intended use. Do not use attachments that are not recommended or sold by the manufacturer; they may cause an unsafe condition.
- 9. Do not install or store the appliance where it will be exposed to the weather or to temperatures below freezing.
- 10. Make sure the appliance is securely installed before operating it.

- 11. To avoid injury, do not touch hot or moving parts.
- 12. Read and observe all notices on the appliance.
- 13. Supervise children closely when they are near or using the appliance.

Limited Warranty

6 Month Limited Warranty

Maxum Air air pumps are warrantied to the original purchaser against defective material and workmanship for 6 months from the date of original purchase. This warranty is valid only under the following conditions: additions, modifications, or changes made to the product by the purchaser and not by the manufacturer shall void this warranty. Damages brought on by abuse, misapplication, or mishandling also voids this warranty.

This warranty is limited to the repair or replacement of the product at the discretion of the manufacturer. This warranty does not cover personal injury, property loss, including livestock or damage (direct, incidental, or consequential) arising out of use of this product. This warranty gives you specific rights and you may also have other rights, which may vary from state to state.

A proof of purchase from an authorized dealer must be provided when making a warranty claim.

Upon discovery of a defect, please call us to obtain an RMA #.

Tel: (310) 672-4099 Tel: (310) 672-4021

All claims should be sent prepaid to the following address:

Transworld Aquatics Enterprises, Inc.

3730 W Century Blvd, Ste. 3 Inglewood, CA 90308

Register your product online at www.jbjaquariums.com/register