


# Reaction HOB

Hang-On-Back Aquarium Power Filter



## Parts Diagram & Identification



▲ HB-05

## Features

1. JBJ Reaction Power Filters hang compactly on the back of your aquarium, keeping your aquascape in focus.
2. Works to reduce particulates in aquarium using a combination of fine and coarse sponge filters.
3. The waterfall-style flow of water helps diffuse CO2 and circulate oxygen throughout the aquarium.

## Quick Installation

Unpack your new Reaction HOB Power Filter. Inspect all its components and confirm all parts are included before using.

Report any damages or missing components to:

Toll Free: (877) 374 9981

Email: [warranty@jbjaquarium.com](mailto:warranty@jbjaquarium.com)

1. Tightly assemble the U-shaped inlet pipe, extension tube, and inlet prefilter.
2. Mount the inlet pipe assembly onto the filter's main body with the regulation valve facing outward.
3. Place filter media inside the reservoir chamber of the filter's main body.
4. Mount the filter onto your aquarium and use the leveling wheel on the bottom of the main body to stabilize the filter parallel to your aquarium.
5. Fill the filter with water and adjust the regulation valve to maximum flow (curved edge facing right).
6. Slide the filter cover over the regulation valve ensuring the guide notches line up with the on the main body slots.
7. Ensure there is enough slack in the power cable to create a drip-loop BEFORE plugging the filter into an electrical socket.
8. Turn on the filter and adjust the flow rate to the ideal setting for your aquarium.

## Notice


1. Always unplug Reaction HOB power filter before inspecting or disassembling for any reason.
2. For best results, disassemble filter and clean it monthly.

## Safety Instructions

### **DANGER - TO AVOID POSSIBLE ELECTRICAL SHOCK.**

Special care should be taken to avoid possible electric shock, since water is employed in the use of aquarium equipment. Do not attempt any repairs by yourself; return the appliance to an authorized service facility for service, or discard the appliance.

1. If the appliance falls into water, DON'T reach for it! First, unplug it and then retrieve it. If electrical components of the appliance get wet, unplug the appliance immediately.
2. Carefully examine the appliance after installation. Unplug the appliance if there is water on parts not intended to get wet.
3. Do not operate any appliance if it has a damaged cord or plug, or if it is malfunctioning, or if it has been dropped or damaged in any manner.
4. Arrange a "drip loop" for each cord connecting an aquarium appliance to an outlet. The "drip loop" is the part of the cord below the level of the outlet that prevents water from traveling along the cord and coming in contact with the outlet.
5. If the plug or outlet should get wet, do not unplug the cord. Disconnect the fuse or circuit breaker that supplies power to the appliance. Once the power has been disconnected, unplug the cord and examine it for the presence of water in the outlet.
6. Always unplug the appliance from an outlet when it is not in use. Also unplug it before cleaning, and prior to disconnecting or attaching parts. Never yank the cord to pull the plug from the outlet. Grasp the plug and pull to disconnect.
7. The filter is designed to operate while filled with water. If the filter runs "dry" over an extended period of time, the motor should be examined to determine if its plastic surfaces have warped or melted. If so, replace the motor.
8. Do not use an appliance for anything other than its intended use. Do not use attachments that are not recommended or sold by the manufacturer; they may cause an unsafe condition.
9. Do not install or store the appliance where it will be exposed to the weather or to temperatures below freezing.
10. Make sure the appliance is securely installed before operating it.



11. This appliance has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit in a polarized outlet only one way. If the plug does not fully fit into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. Do not attempt to defeat this safety feature.
12. To avoid injury, do not touch hot or moving parts.
13. Read and observe all notices on the appliance.
14. Supervise children closely when they are near or using the appliance.

## Limited Warranty

### **6 Month Limited Warranty**

Reaction HOB filters are warrantied to the original purchaser against defective material and workmanship for 6 months from the date of original purchase. This warranty is valid only under the following conditions: additions, modifications, or changes made to the product by the purchaser and not by the manufacturer shall void this warranty. Damages brought on by abuse, misapplication, or mishandling also voids this warranty.

This warranty is limited to the repair or replacement of the product at the discretion of the manufacturer. This warranty does not cover personal injury, property loss, including livestock or damage (direct, incidental, or consequential) arising out of use of this product. This warranty gives you specific rights and you may also have other rights, which may vary from state to state.

A proof of purchase from an authorized dealer must be provided when making a warranty claim.

Upon discovery of a defect, please call us to obtain an RMA #.

Tel: (310) 672-4099

Tel: (310) 672-4021

All claims should be sent prepaid to the following address:

### **Transworld Aquatics Enterprises, Inc.**

3730 W Century Blvd, Ste. 3

Inglewood, CA 90308

**Register your product online at [www.jbjaquariums.com/register](http://www.jbjaquariums.com/register)**